

User Manual  
**FV64UP**  
Automatic Dual-Mode  
Nitrogen Concentrator  
*More Intelligent, More Efficient*



# Cautions

**With nozzle automatic lifting function, it is only allowed to close or open the top cover after all nozzles rise to the top, otherwise the equipment may be damaged.**

**Nozzles will be automatically back to the top after powering on.**

**Please ensure all nozzles have risen to the top before opening the cover under any power-off circumstances (seeV.2.).**

Please be acquainted with the following icons before using this equipment.



Warning Danger (please be careful and note safety)



Key Information (please kindly notice)



Please keep distance from the top cover when making nozzle replacements.



Caution Electricity



Caution Electricity



Drain Outlet



Gas Inlet



Beware of Pointed  
Nozzles

# CONTENTS ▶▶▶

<b>Cautions</b>	01
<b>CONTENTS</b>	02
<b>Announcements</b>	03
<b>I. Introduction</b>	04
<b>II. Unpacking Instructions</b>	04
<b>III. Installation</b>	05
<b>IV. Environment</b>	05
<b>V. Hardware</b>	05
1. Control Terminal	06
2. Top Cover	06
3. Nozzle & Channel	06
4. Water Bath	06
5. Exhaust Device	06
6. Electromagnetic Lock	07
7. Lighting	07
8. Power Socket & Button	07
9. Drainage Outlet	07
10. Manual Reset	07
<b>VI. Software</b>	08
1. Main Interface	08
2. Method Settings	12
3. System Settings	15
4. Nozzle Replacements	15
<b>VII. Operation</b>	16
1. Running Mode Switch	16
2. Working Instructions	16
3. Nozzle Replacement	19
<b>VIII. FAQ &amp; Solutions</b>	19
<b>IX. Service</b>	20
<b>Statement</b>	21